

# BSCK22

## Hose Repair Kit for 1/4" I.D. Hose

**Instructions:** Insert hose with ferrule and splicer or nut and nipple in crimping tool. Offset tool approximately 1/8" from end of ferrule and apply pressure. Make 1/4 turn and apply pressure again.

**Kit Contents:** Also contains BSC3 Crimping Tool.

