

# BSCK26

## Hose Repair Kit for 1/4" I.D. Hose

**Instructions:** Insert hose with ferrule and splicer or nut and nipple in crimping tool. Offset tool approximately 1/8" from end of ferrule and apply pressure. Make 1/4 turn and apply pressure again.

**Kit Contents:** Also contains BSC5 Crimping Tool.



<p>30 (2pc)</p> <p>B to B Hose Coupler RH</p>	<p>31 (2pc)</p> <p>B to B Hose Coupler LH</p>	<p>9940-P (3pc)</p> <p>Hose Brace</p>	<p>7325 (4pc)</p> <p>Hose Ferrule</p>	<p>3588 (6pc)</p> <p>Hose Ferrule</p>	<p>7326 (6pc)</p> <p>Hose Ferrule</p>
<p>7 (6pc)</p> <p>B size nut, RH</p>	<p>8 (6pc)</p> <p>B size nut, LH</p>	<p>17 (6pc)</p> <p>B size nipple, 1/4" barb</p>	<p>17 (6pc)</p> <p>B size nipple, 1/4" barb</p>	<p>44 (2pc)</p> <p>Hose Splicer 1/4"</p>	<p>7326 (6pc)</p> <p>Hose Ferrule</p>