

BSCK5

Hose Repair Kit for 3/16" & 1/4" I.D. Hose

Instructions: Insert hose with ferrule and splicer or nut and nipple in crimping tool. Offset tool approximately 1/8" from end of ferrule and apply pressure. Make 1/4 turn and apply pressure again.

Kit Contents: Also contains BSC5 Crimping Tool.

