



200DISINFECTANT

Hospital Grade
Neutral pH Disinfectant
Disinfectant/Deodorizer Cleaner

Features

- Cleans, disinfects and deodorizes artificial turf surfaces, mats, floors, walls, mirrors, windows, plastic surfaces, metal surfaces, sickroom equipment, instrument storage, locker rooms and swimming pool surfaces.
- Virucidal and inhibits the growth of mold and mildew and their odors.
- Effective disinfectant activity against:

HIV-1 Avian Influenza A Virus Salmonella enterica Canine Distemper Virus Hepatitis B virus (HBV) E. Coli Pasteurella Hepatitis C virus (HCV) **Pseudorabies Virus** Herpes Simplex Type 1 **Canine Parvovirus** Staphylococcus Herpes Simplex Type 2 **VRE** Streptococcus **MRSA** Influenza A Virus and many more. Coronavirus **VISA** Feline Picomavirus **CA-MRSA**

- Mildew control on enamel, porcelain, tile, and plastics and cleaner for walls, floors, and industrial work areas, garbage cans and trucks, industrial waste receptacles, cellars and basements.
- Water and smoke damage restoration for odor causing bacterias on synthetic fibers. Dilute 2 to 4 ounces per gallon of water.

Technical Specifications

Material: Didecyl Dimethyl Ammonium Chloride & Dimethyl benzyl ammonium chloride

Color: Green liquid
Fragrance: Mint

pH: 7.20 (concentrate)

Flash point: None. Nonflammable

Quat type: Quaternary ammonium chloride

Authorization: EPA registered. USDA authorized

for use in federally inspected meat and poultry plants

Weight: 1 gallon

Packaging: Four 1 gallon bottles/Box

Country of origin: USA

Applications

For disinfecting, deodorizing and cleaning nonporous inanimate surfaces intended for sports stadiums, athletic/recreational facilities, locker rooms, convention centers, hospitals, institutions, schools, nursing homes, factories, offices, veterinary clinics, zoos, or any building to maintain sanitary premises.

Usage Instructions

DISINFECTION - To disinfect hard, inanimate surfaces apply solution so as to wet all surfaces thoroughly. Allow to remain wet for 10 minutes and then remove excess liquid. For heavily soiled areas, a pre-cleaning step is required. Prepare a fresh solution for each use.

GENERAL DISINFECTION - Add 2 ounces of this product per gallon of water.

MILDEWSTAT - To control mold and mildew clean surfaces then add 2oz. of this product per gallon of water Apply, making sure to wet surfaces completely. Let air dry.

This product is not to be used as a terminal sterilant/high level disinfectant on any surface or instrument that (1) is introduced directly into the human body, either into or in contact with the bloodstream or normally sterile areas of the body, or (2) contacts intact mucous membranes but which does not ordinarily penetrate the blood barrier or otherwise enter normally sterile areas of the body. This product may be used to preclean or decontaminate critical or semi-critical medical devices prior to sterilization or high level disinfection.



WWW.TECHNIWELDUSA.COM